


19 412 000 CHIARA THERMOSTAT-BRAUSEBATTERIE



ERSATZTEILE, August 2007 – now

1: Temperaturwählgriff (Order-nr. 47692IP0)

1.1: Abdeckkappe (Order-nr. 11366P0M)

2: Absperrgriff (Order-nr. 47695IP0)

2.1: Abdeckkappe (Order-nr. 11366P0M)

3: Rosette (Order-nr. 47696000)


4: Keramik-Oberteil 1/2" (Order-nr. 45346000)

4.1: O-Ring Ø18,2 x Ø1,7 (Order-nr. 0392400M)

5: Verlängerungsset 27,5 mm (Order-nr. 47780000)*

* Optional accessories

19 412 000 CHIARA THERMOSTAT-BRAUSEBATTERIE



ERSATZTEILE, November 2005 – August 2007

1: Temperaturwählgriff (Order-nr. 47692IP0)

1.1: Abdeckkappe (Order-nr. 11366P0M)

2: Absperrgriff (Order-nr. 47695IP0)

2.1: Abdeckkappe (Order-nr. 11366P0M)

3: Rosette (Order-nr. 47696000)

4: Hülse (Order-nr. 08239000)

5: Keramik-Oberteil 1/2" (Order-nr. 45346000)

6: Verlängerungsset 27,5 mm (Order-nr. 47780000)*

* Optional accessories